


1604-VLZ[™] 16 CHANNEL MIC/LINE MIXER



SERVICE MANUAL

Contents	Pg.
Quick Parts	1
Block Diagram	2
Channel Schematic	3
Pod Section Schematics	4-6
Pod Section PCB Layout	7-8
Main Section Schematics	9-14
Main Section PCB Layout	15
Jumper Location and Pinout	16
Power Supply	17

MACKIE DESIGNS INC., 16220 WOOD-RED ROAD, WOODINVILLE, WA 98072, USA 820-172-00 05/99



SCREWFLACEMENT		SOREWFLACEMENT	META	L
TOPALLEN SCREWS	SIDESCREWS	XLRSCREWS	CHASSIS BOTTOM	FOD BOTTOM
'00-011 - 00	700-006-00	700-005-00	550-173-00	550-175-00
OTTOM SCREWS	END CAPSCREWS	STARGROUND	CHASSIS TOP	POD TOP
01-002-00	700-010-06	screw 700-031-01	550-172-10	550-174-00
		nut 705-001-00	000-172-10	330-174-00
SIDE POD SCREWS	PLATESCREWS		CABLE PLATE	BUMPON
700-004-00	700-010-00		550-176-00	750-001-00

POD COMPONENTS...

ALL 1/4" JACKS jack 400-214-00 washer710-00200 nut 705-003-00

FEMALEXLRINFUT 400-223-00

RCA IN/OUT 400-022-00

IECRECEPTICLE 400-009-00

PWRSWITCH 500-013-00

FHANTOM SW 500-016-00

MONO CUTFUT knob: 760-007-00 pot: 130-062-02

INTERNAL PARTS...

TRANSFORMER100V 080-008-02
120V 080-008-00
230V 080-008-01


PCB-POD 055-219-00-01


PCB-MAIN 055-220-00-01


PCB-PWR 055-066-00


MISC... ROTO RACK EARS L - 550-179-00 R- 550-180-00 RACK EARS 550-177-00 (X2) ACLINECORD (120V) 640-001-00


OWNER SMANUAL 820-034-01














CHANNELS 1-2 SHOWN, 3-16 SIMILAR









REV C








REV C









































MACKIE DESIGNS PRIMARY CIRCUIT 450-066-00 B

MAGRIE.

CR1604-VLZ POWER SUPPLY





THE MACKIE FIXER • MACKIE DESIGNS SERVICE NEWS

1604-VLZ Auxiliary modifications

In addition to the modifications shown in the 1604-VLZ owner's manual, there are two rather lovely and optional mods for the signal routing of Aux 3/4 and 5/6.

UL Warning

CAUTION! These modification instructions are for use by qualified personnel only. To avoid electric shock, do not perform any servicing other than changing the fuse unless you are qualified to do so. Refer all servicing and modifying to qualified personnel.

Mackie Disclaimer

Any modification of any Mackie Designs product must be performed by a competent electronic technician. Mackie Designs accepts no responsibility for any damages or injuries caused by any modification, regardless of the source of the modification instructions or the qualifications of the technician performing them. In the case of such damages, Mackie Designs may declare warranty privileges void. BE CAREFUL!

About Jumpers

We recommend solid (non-stranded) insulated wire, 26–28 gauge (wire-wrapping variety). When installing jumpers, do not run their ends through holes in the circuit board. Rather, solder them flat against the desired pad (the flat silver area, possibly with a hole in the middle). Make sure the ends of these flat wires do not extend beyond the pad.

Tools required

Sharp razor (X-acto) knife, soldering iron, solder, Phillips screwdriver.

Getting ready

The following must be performed before starting the actual mods.

- 1. Remove all cords, including the power cable, from the 1604-VLZ.
- 2. Place the mixer upside-down on a dry, non-marring surface.
- 3. If you have converted your mixer to the rack-mount position or have installed a RotoPod, undo those changes and temporarily configure the mixer in the original desktop mode. You do not have to install the pod, just get it out of the way of the bottom cover.
- 4. Remove the screws that attach the bottom cover. Keep track of what screws go where. Remove the bottom cover and have at the mods shown on sheet 2.
- 5. When you have finished the mods, put it all back together and retest all fuctions for correct operation, making especially sure that all modified channels are working correctly.

THE MACKIE FIXER • MACKIE DESIGNS SERVICE NEWS


To make Aux 3/5 and Aux4/6 Pre-EQ and Pre-Fader

Aux 3/5

- Cut the trace between the round and square pads at point **D** on the channel to be modified.
- Solder an insulated jumper wire from the square pad at **D** to the square pad at **F** on the same channel.
- 3. Repeat for other channels as required.

Aux 4/6

- Cut the trace between the round and square pads at point E on the channel to be modified.
- 2. Solder an insulated jumper wire from the square pad at **E** to the square pad at **F** on the same channel.




To make Aux 3/5 and Aux4/6 Post-EQ and Pre-Fader

Aux 3/5

- Cut the trace between the round and square pads at point **D** on the channel to be modified.
- Solder an insulated jumper wire from the square pad at **D** to the square pad at **B** on the same channel.
- 3. Repeat for other channels as required.


Aux 4/6

- 1. Cut the trace between the round and square pads at point **E** on the channel to be modified.
- Solder an insulated jumper wire from the square pad at E to the square pad at B on the same channel.
- 3. Repeat for any other channels as required.





1604-VLZ Aux mod, sheet 2 of 3


THE MACKIE FIXER • MACKIE DESIGNS SERVICE NEWS



MACKIE DESIGNS CR-1604 VLZ PRO REV 12-3-1998







POD BOARD 219 REV B

©1998 Mackie Designs Inc. All rights reserved

